



H700 / H400 / H300 W400 SMART

THE CHOICE OF LANGUAGE IS LIMITED AND DIFFERS BETWEEN ALEXA AND GOOGLE. ALL VOICE COMMANDS LISTED ARE EXAMPLES. SIMILAR, SLIGHTLY MODIFIED SENTENCES MAY ALSO WORK.



BONECO

FAN SPEED		POWER SWITCH / ON OFF	
EN	"SET THE <DEVICE NAME> <RANGE NAME> TO <VALUE>"	EN	"TURN ON THE <DEVICES NAME>."
US	"SET THE <RANGE NAME> ON THE <DEVICE NAME> TO MAXIMUM"	US	"TURN OFF THE <DEVICE NAME>."
	"DECREASE THE <RANGE NAME> ON THE <DEVICE NAME> BY <VALUE>"		
	"WHAT'S THE <DEVICE NAME> <RANGE NAME>?"	IT	"ACCENDI L'<DEVICE NAME>."
	"TURN UP THE <DEVICE NAME> <RANGE NAME>"		"SPEGNI LE <DEVICE NAME>."
IT	"IMPOSTA LA <RANGE NAME> SU 7"	JP	"<DEVICE NAME> をつけて"
	"IMPOSTA AL MASSIMO LA <RANGE NAME> DELLA CAMERA DA LETTO."		"<DEVICE NAME> を消して"
	"AUMENTA LA <RANGE NAME> DELLA CAMERA DA LETTO."	DE	"<DEVICE NAME> EINSCHALTEN."
	"RIDUCI DI <VALUE> LA <RANGE NAME> DELLA CAMERA DA LETTO."		"SCHALTE DAS <DEVICE NAME> AUS."
	"QUAL È LA <RANGE NAME> DELLA CAMERA DA LETTO?"	ES	"ENCIENDE LA <DEVICE NAME>."
JP	"<DEVICE NAME>の<RANGE NAME>を<VALUE>にして"		"APAGA LAS <DEVICE NAME>."
	"<DEVICE NAME>の<RANGE NAME>を最大にして"	PT	"DESLIGUE AS <DEVICE NAME>"
	"<DEVICE NAME>の<RANGE NAME>を上げて"		"APAGUE AS <DEVICE NAME>"
	"<DEVICE NAME>の<RANGE NAME>を<VALUE>弱めて"		"LIGUE O <DEVICE NAME>"
	"<DEVICE NAME>の<RANGE NAME>は?"	FR	"ALLUME L'<DEVICE NAME>."
DE	"STELLE DIE <RANGE NAME> AUF <VALUE>"		"ÉTEINS LES <DEVICE NAME>."
	"STELLE DIE <RANGE NAME> AUF MAXIMUM"		
	"ERHÖHE DIE <RANGE NAME> DES <DEVICE NAME>"		
	"VERRINGERE DIE <RANGE NAME> AUF <DEVICE NAME> UM <VALUE>"		
	"WAS IST DIE <RANGE NAME> AUF <DEVICE NAME>?"		
ES	"PON LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME> EN <VALUE>."		
	"PON LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME> AL <VALUE>."		
	"SUBE LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME>."		
	"REDUCE LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME> EN <VALUE>."		
	"REDUCE LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME> A <VALUE>."		
	"¿CUÁL ES LA <RANGE NAME> DEL <DEVICE NAME> DEL <ROOM NAME>?"		
PT	"MUDE A <RANGE NAME> DO QUARTO PARA <VALUE>"		
	"COLOQUE A <RANGE NAME> DO QUARTO AO MÁXIMO"		
	"AUMENTE A <RANGE NAME> DO QUARTO"		
	"DIMINUA A <RANGE NAME> DO QUARTO EM <VALUE>"		
	"QUAL É A <RANGE NAME> DO QUARTO?"		
FR	"RÈGLE LA <RANGE NAME> DU <DEVICE NAME> DE LA <ROOM NAME> À <VALUE>"		
	"RÈGLE LA <RANGE NAME> DU <DEVICE NAME> DE LA <ROOM NAME> AU <VALUE>."		
	"AUGMENTE LA <RANGE NAME> DU <DEVICE NAME> DE LA <ROOM NAME>."		
	"DIMINUE LA <RANGE NAME> DU <DEVICE NAME> DE LA <ROOM NAME> DE <VALUE>."		
	"QUELLE EST LA <RANGE NAME> DU <DEVICE NAME> DE LA <ROOM NAME>?"		

IT = ITALIAN, JP = JAPANESE, DE = GERMAN, ES = SPANISH, PT = PORTUGUESE, FR = FRENCH
SE = SWEDISH, KR = KOREAN, NL = DUTCH, EN / US = ENGLISH,

RANGE NAME 1	RANGE NAME 2	RANGE NAME 3
EN FAN SPEED	EN FAN LEVEL	EN FAN SETTING
IT VELOCITÀ DELLA VENTOLA	IT LIVELLO DELLA VENTOLA	IT IMPOSTAZIONE DELLA VENTOLA
JP ファン速度 (FAN SOKUDO)	JP ファンレベル (FAN REBERU)	JP ファン設定 (FAN SETTEI)
DE LÜFTERGESCHWINDIGKEIT	DE LÜFTERSTUFE	DE LÜFTEREINSTELLUNG
ES VELOCIDAD DEL VENTILADOR	ES NIVEL DEL VENTILADOR	ES AJUSTE DEL VENTILADOR
PT VELOCIDADE DO VENTILADOR	PT NÍVEL DO VENTILADOR	PT CONFIGURAÇÃO DO VENTILADOR
FR VITESSE DU VENTILATEUR	FR NIVEAU DU VENTILATEUR	FR RÉGLAGE DU VENTILATEUR



H700 / H400 / H300 W400 SMART

THE CHOICE OF LANGUAGE IS LIMITED AND DIFFERS BETWEEN ALEXA AND GOOGLE. ALL VOICE COMMANDS LISTED ARE EXAMPLES. SIMILAR, SLIGHTLY MODIFIED SENTENCES MAY ALSO WORK.



GOOGLE
ASSISTANT



FAN SPEED

EN "OK GOOGLE, SET <DEVICE NAME> TO 7."

IT = ITALIAN, JP = JAPANESE, DE = GERMAN, ES = SPANISH, PT = PORTUGUESE, FR = FRENCH
SE = SWEDISH, KR = KOREAN, NL = DUTCH, EN / US = ENGLISH,



POWER SWITCH / ON OFF

EN "OK GOOGLE, TURN ON <DEVICE NAME>."
US "OK GOOGLE, TURN OFF <DEVICE NAME>."

IT "ACCENDIMI <DEVICE NAME>"
"HO SPENTO <DEVICE NAME> ?"
"HO LASCIATO <DEVICE NAME> ACCESO?"
"SPEGNI <DEVICE NAME>"

JP "<DEVICE NAME> はついてる"
"<DEVICE NAME> で何がオンになっていますか"
"<DEVICE NAME> をつけて"
"<DEVICE NAME> をオフにして"
"<DEVICE NAME> をオンにして"
"<DEVICE NAME> を消して"

DE "BITTE <DEVICE NAME> AUS"
"BITTE <DEVICE NAME> EINSCHALTEN"
"BITTE <DEVICE NAME> AUSSTELLEN"
"IST <DEVICE NAME> AN?"
"<DEVICE NAME> AN"

ES "ENCIENDE <DEVICE NAME>"

PT "ACENDER <DEVICE NAME>"
"APAGAR <DEVICE NAME>"

FR "TU PEUX ÉTEINDRE <DEVICE NAME> ?"
"ALLUME <DEVICE NAME>"
"EST-CE QUE <DEVICE NAME> EST ÉTEINTE"
"QU'EST-CE QUI EST ALLUMÉ DANS <DEVICE NAME>"
"ÉTEINS <DEVICE NAME>"

SE "STÄNG AV <DEVICE NAME>"
"SÄTT PÅ <DEVICE NAME>"
"VAD ÄR PÅ I <DEVICE NAME>"
"ÄR <DEVICE NAME> PÅ?"

KR "<DEVICE NAME> 꺼 줘"
"<DEVICE NAME> 전원 켜"
"<DEVICE NAME> 꺼 줘"
"<DEVICE NAME> 켜져 있어"
"<DEVICE NAME> 전원 꺼 줘"
"<DEVICE NAME> 에 뭐 켜져 있어"

NL "<DEVICE NAME> AANDOEN"
"DOE <DEVICE NAME> AAN"
"DOE <DEVICE NAME> UIT"
"STAAT <DEVICE NAME> AAN"
"STAAT ER IETS AAN IN <DEVICE NAME>"